

SIDE GATE PM HIT LIST:

1. Autolock Assy Adjustment & Lube

Spray Lube (with Silicone) on Pockets and Grease Shaft Keepers x (2)

2. Grease Rollers x (4) with Lithium Based # 2 Grease

3. Proper Skid Wear Pad Adjustment x (4)

4. Proper Chain Adjustment



Good Chain Adjustment



Bad Chain Adjustment



Good Skid Wear Pad Adjustment



Bad Skid Wear Pad Adjustment

SIDE GATE PM REMAINING STEPS:

5. Grease all fittings - See Page 2 for location of fittings

(20 fittings with **SINGLE CHAIN** – 22 fittings with **DUAL CHAIN**)

6. Check Bushings

- Platform: Tension Arms, Compression Arms
- Idler Sprockets

7. Inspect all electrical connections for broken, frayed or corrosion

8. Inspect all hardware for broken, missing roll pins, bolts, nuts, fasteners



PM PARTS LOCATIONS

- 1 Lifting Cylinder (x4)**
- 2 Tension Arm (x4)**
- 3 Compression Arm (x4)**
- 4 Idler Sprocket (x2)**
- 5 Skid Pad/Rollers (x4)**
- 6 1 Chain Sprockets (x2)**
- 7 2 Chain Sprockets (x4)**
- 8 Auto Lock (x2)**

